BYRNE

INSTALLATION INSTRUCTIONS FOR HOLE MOUNT BURELÉ

Install data jacks as described in the installation instructions provided with data adapters, BE01421

Drill 2 - 5/16" Diameter Hole

320 Byrne Industrial Drive, Rockford, MI 49341
IS03516 © 2018 Byrne Electrical Specialists, Inc. All Rights Reserved

www.byrne.com
P 800.999.3567

1 of 1
01/02/2018