


BYRNE

INSTALLATION INSTRUCTIONS FOR RIALTO

Lay Rialto Starter, Intermediate and/or Power on floor or large flat surface.



RAILTO STORAGE INSTRUCTIONS:

- 1) Unplug Rialto and all electrical devices connected to it.
- 2) Separate Rialto into modular pieces (Powerbase, Intermediate & Starter).
- 3) Slide each piece into carrying case, using a separate compartment for each.
Any alignment pins should be at the top where the case closes.
- 4) Use velcro to secure case cover.
- 5) Use handles of carrying case to transport Rialto.