

BYRNE

INSTALLATION INSTRUCTIONS FOR ELLORA WELL®


Install data jacks as described in the installation instructions provided with data adapters, BE01421


Ellora B Z		"X" Dim.
BE06031	4 Windows	7-7/8"
BE06031	6 Windows	10-7/8"














Note: In a conduit application, conduit should be supported according to local code. When managing conduit and cabling exiting the unit, ensure there is adequete slack to allow unit to open properly